

Note: Pre-conditioning (PC) to simulate customer manufacturing and rework processes is required for the package accelerated environmental stress tests (test group A). See Tables 1 & 2 for applicability of each test.

